

Pre-loaded Single Use Injectors

Heiden Bliss
Biomark, Inc.

Biomark first developed the Pre-loaded Single Use Injector (SUI) in 2008 for use during mass-marking projects. The Pre-loaded SUI consists of a high-performance 12.5mm, 134.2 kHz PIT Tag loaded into a 13 gauge needle. Each needle has a small silicone bump inside that prevents the tag from falling out of the needle prior to tagging. The Pre-loaded SUI typically comes in trays of 100 for efficient handling and marking. The SUIs are assembled locally at Biomark in Boise, ID for better QA/QC control. The Pre-loaded SUI can be sent back to Biomark to be recycled and the trays may be sent back to be reused.